

CADILLAC

MODEL 314. SERIAL NUMBERS 100,001 UP (1926) DELCO GENERATING, STARTING AND LIGHTING SYSTEM DELCO IGNITION

BATTERY:—Exide, Type 3-LXRV-15-2G, 6 volt, 130 ampere hour. The starting capacity is 137 amperes for 20 minutes. Lighting capacity is 5 amperes for 26 hours. The positive (+) terminal is grounded.

IGNITION:—Coil Model 2189. Distributor Model 5281. Breaker contacts separate .025 inch. They are made of tungsten. When the condition of the contacts affects the ignition, remove and resurface on a medium hard oilstone or with a fine, flat jewelers' file. The tension of the contact arm spring should be 16-20 ounces. Manual advance is 18-22°. Automatic advance begins at 600 R.P.M. and reaches a maximum of 30° at 2800 R.P.M.

Oiling:—Put 8 or 10 drops of light engine oil in the oiler on the side of the distributor housing every month or each 1000 miles if the car is driven more than 1000 miles in a month.

Mounting:—Distributor is mounted between the cylinder banks and is driven by spiral gears from the cam shaft. To remove unit, remove hold down screw and lift from position.

Timing:—One set of breaker contacts begins to separate when piston No. 1 on compression stroke reaches a position at which the flywheel marking IG/A-1/5 is opposite the indicator on the flywheel case. This is approximately 1 27/32 inches before top dead center. The manual advance lever must be in the fully advanced position. The other set of contacts open when the engine has turned over 90° (or 45° of the distributor). In this position the flywheel marking IG/A-2/6 is opposite the indicator.

Firing Order:—The firing order is 1L-4R-4L-2L-3R-3L-2R-1R.

Spark Plugs:—Spark plug diameters are 7/8 inch. Gaps are .025 inch.

STARTER:—Model No. 314. Starter is connected to the engine through a pinion shift incorporated in the starting pedal. The direction of rotation is counter-clockwise, looking at the commutator end. Starter cranks the engine at 104 R.P.M. taking 140-150 amperes. Starter brush tension should be 2 1/4-2 1/2 pounds each.


Starter Data			
Torque	R.P.M.	Volts	Amperes
0 lb. ft.	Free	6.	60
18.25 lb. ft.	Lock	3.2	

Mounting:—Starter is mounted vertically at the rear of the engine. To remove, loosen set screw in steering column and remove starting pedal button and accelerator pedal. Then remove toe boards and disconnect hand throttle rod and foot throttle rod. Remove three hold down screws and lift starter from place.

Oiling:—Self-lubricating bearings are used. They require no attention.

GENERATOR:—Model No. 315. The direction of rotation is counter-clockwise, looking at the commutator end. Generator current regulation is by the third brush system. To adjust the generator output, shift the third brush mounting plate by turning the hexagonal nut on the outside of the generator end plate. Turning the nut in a clockwise direction increase the charging rate and in the opposite direction decreases the charging rate. The maximum output is 15-17 amperes reached at 1000 R.P.M. of the generator armature.

Generator Data		
Amperes	Volts	Amperes
2		500
15		1000
15-17	7.5-8	Peak



CADILLAC

MODEL 314. SERIAL NUMBERS 100,001 UP (1926) DELCO GENERATING, STARTING AND LIGHTING SYSTEM DELCO IGNITION

The brush tension should be 1-1¼ pounds each. Shunt field current is 3 amperes at 7.5 volts.

Mounting:—Generator is mounted at the front of the engine between the cylinder banks and is belt driven. Care must be taken to see that the belt is not tight enough to crowd the generator bearings nor so loose that excessive slipping is possible. To remove generator, loosen the four mounting nuts at the forward end of the generator and lower the unit so that the belt can be removed. Then remove nuts and lift generator from position.

Oiling:—Put 8 or 10 drops of light engine oil in each of the generator bearing oilers every two weeks or each 500 miles if the car is driven more than 500 miles in two weeks.

RELAY:—Relay contacts close at 10-12 M.P.H. when the voltage of the generator reaches 6.75-7.5 volts and open with a discharge current of 0-3 amperes. Air gap between relay armature and coil core is .009-.010 inch, contacts closed.

LIGHTING:—Switch Model 1287. Head lamps use a double filament bulb. They are 6-8 volt, 21 cp. Dimmer lamps are 6-8 volt, 3 cp. S.C. Dash, dome, tonneau and tail lamps are 6-8 volt, 3 cp. S.C. Backing and stop lamps are 6-8 volt, 21 cp. S.C.

CIRCUIT BREAKER:—Model 5767. A combined vibrating and lockout circuit breaker is mounted on the dash. The vibrating unit protects the lighting circuit. A current of 25-30 amperes causes it to operate. While vibrating the current flow is 10-15 amperes. The lockout circuit breaker protects the horn, inspection lamp, stop and backing lamp and cigar lighter circuits. A current of 25-30 amperes causes it to open the circuit. While operating the current flow is less than 1 ampere.

