



TECH TIPS

Alternator Pulley Installation Guide

1. When installing a pulley and fan on an alternator carefully inspect the pulley for excessive wear. When in doubt, replace the pulley. It is not recommended to reuse the old clutch/de-coupling pulleys!
2. Use the proper tools to install and torque the pulley and fan. Some of the types of tools available are shown below.



3. The fan and pulley must be torqued to the manufacturer's specifications.
4. Measure the pulley position from the alternator being replaced and make note of it before removing the pulley and spacers. Use the appropriate reference point when taking measurements as shown in the picture below.





TECH TIPS

5. Remove and install the pulley with the shaft in the horizontal position, shown below, to prevent damage to internal components.



6. Pull the rotor out wards from the alternator, some alternators are designed with a sliding fit in the bearing and the rotor may have moved inwards during shipping and handling.
7. Install the pulley, spacers and nut (hand tightened only) and measure the position to ensure the belt will align properly, again from the appropriate reference point as shown above.
8. Torque the pulley to the manufacturer's specifications. Failure to do this could result in severe alternator damage and/or vehicle damage.