Colt Industries — Fairbanks Morse Engine Accessories Division
BELOIT, WISCONSIN

SERVICE INFORMATION MAGNETO REPAIR KITS

Part No.	Quantity	Description
		KIT NO. SK1 for FM-J1 CW MAGNETOS
AXMR2433	1	Condenser
R2437	1	Point Set
A5931B	1	Lockwasher
10S12D	4	End Cap Screw
GK16	1	Gasket Kit
		KIT NO. SK2 for FM-J1 CCW MAGNETOS
AXMR2433	1	Condenser
S2437	1	Point Set
A5931B	1	Lockwasher
10S12D	4	End Cap Screw
GK16	1	Gasket Kit
		KIT NO. SK3 for FM-J4 CW MAGNETOS
AXMR2433	1	Condenser
R2437	1	Point Set
E2460B	1	Brush Assembly
M2765	1	Distributor Rotor
A5931B	1	Lockwasher
10S14D	4	End Cap Screw
GK17	1	Gasket Kit
		KIT NO. SK4 for FM-J4 CCW MAGNETOS
AXMR2433	1	Condenser
S2437	1	Point Set
E2460B	1	Brush Assembly
M2765	1	Distributor Rotor
A5931B	1	Lockwasher
10S14D	4	End Cap Screw
GK17	1	Gasket Kit
		KIT NO. SK5 for FM-JV4B7 MAGNETOS
SXY2433	1	Condenser
T2437	1	Point Set
E2460B	1	Brush Assembly
M2765	1	Distributor Rotor
10S12D	4	End Cap Screw
GK17	1	Gasket Kit
		KIT NO. SK6 for FM-X1 CW MAGNETOS
AXMR2433	1	Condenser
A2437A	1	Point Set
G2788	1	Cam Wick
A5931B	1	Lockwasher
10S12D	4	End Cap Screw
GK16	1	Gasket Kit
		KIT NO. SK7 for FM-X1 CCW MAGNETOS
AXMR2433	1	Condenser
B2437A	1	Point Set
H2788	1	Cam Wick
A5931B	1	Lockwasher
10S12D	4	End Cap Screw
GK16	1	Gasket Kit
		KIT NO. SK8 for FM-XD1B7 MAGNETOS
AXMR2433	1	Condenser
A2437A	1	Point Set
G2788	1	Cam Wick
10S12D	1	End Cap Screw
GK16	1	Gasket Kit
		KIT NO. SK9 for FM-XV4B7 MAGNETOS
SXY2433	1	Condenser
A2437A	1	Point Set
E2460B	1	Brush Assembly
M2765	1	Distributor Rotor
		KIT NO. SK9 (Continued)
10S12D	4	End Cap Screw
GK17	1	Gasket Kit
		KIT NO. SK10 for FM-J2A and 2B MAGNETOS
AXMR2433	1	Condenser
S2437	1	Point Set
E2460B	1	Brush Assembly
N2765	1	Distributor Rotor
A5931B	1	Lockwasher
10S14D	4	End Cap Screw
GK16	1	Gasket Kit
		KIT NO. SK11 for FM-B2B6 CCW BATTERY IGNITION UNITS
RX2433	1	Condenser
B2437A	1	Point Set
E2460B	1	Brush Assembly
M2765	1	Distributor Rotor
10S12D	4	End Cap Screw
GK26	1	Gasket Kit
		KIT NO. SK12 for FM-B4B CW BATTERY IGNITION UNITS
RX2433	4	Condenser
A2437A	1	Point Set
E2460B	1	Brush Assembly
M2765	1	Distributor Rotor
10S12D	4	End Cap Screw
GK26	1	Gasket Kit
		KIT NO. SK13 for FM-X4 CW MAGNETOS
AXMR2433	1	Condenser
A2437A	1	Point Set
E2460B	1	Brush Assembly
M2765	1	Distributor Rotor
A5931B	1	Lockwasher
10S14D	4	End Cap Screw
GK17	1	Gasket Kit
		KIT NO. SK14 for FM-X4 CCW MAGNETOS
AXMR2433	1	Condenser
B2437A	1	Point Set
E2460B	1	Brush Assembly
M2765	1	Distributor Rotor
A5931B	1	Lockwasher
10S14D	4	End Cap Screw
GK17	1	Gasket Kit
		KIT NO. SK15 for FM-K4 CW MAGNETOS
AXMR2433	1	Condenser
P2437	1	Point Set
A5931B	1	Lockwasher
10S12D	4	End Cap Screw
GK15	1	Gasket Kit
		KIT NO. SK16 for FM-K4 CCW MAGNETOS
AXMR2433	1	Condenser
Q2437	1	Point Set
A5931B	1	Lockwasher
10S12D	4	End Cap Screw
GK15	1	Gasket Kit
		KIT NO. SK17 for FM-H4 and H6, FM-04 and 06, FM-0H4 and 0H6, FM-0R4 and 0R6 and FM-R4 and R6 CW MAGNETOS
RX2433	1	Condenser
P2437	1	Point Set
		KIT NO. SK17 (Continued)
A5931B	1	Lockwasher
10S12D	4	End Cap Screw
GK25	1	Gasket Kit
		KIT NO. SK18 for FM-H4 and H6, FM-04 and 06, FM-0H4 and 0H6, FM-0R4 and 0R6, and FM-R4 and R6 CCW MAGNETOS
RX2433	1	Condenser
Q2437	1	Point Set
A5931B	1	Lockwasher
10S12D	1	End Cap Screw
GK25	1	Gasket Kit
		KIT NO. SK19 for FM-XR4A and B, FM-XR6A and B, FM-XOR4A and B, and FM-XOR6A and B CW MAGNETOS
SXY2433	1	Condenser
A2437A	1	Point Set
A5931B	1	Lockwasher
10S12D	4	End Cap Screw
GK25	1	Gasket Kit
		KIT NO. SK20 for FM-XR4A and B, FM-XR6A and B, FM-XOR4A and B, and FM-XOR6A and B CCW MAGNETOS
SXY2433	1	Condenser
B2437A	1	Point Set
A5931B	1	Lockwasher
10S12D	4	End Cap Screw
GK25	1	Gasket Kit
		KIT NO. SK21 For FM-J2A and 2B CCW MAGNETOS
AXMR2433	1	Condenser
S2437	1	Point Set
D2460A	2	Dist. Brush Assembly
E2460B	1	Brush Assembly
N2765	1	Distributor Rotor
A5931B	1	Lockwasher
10S14D	4	End Cap Screw
GK16	1	Gasket Kit
		KIT NO. SK22 for FM-J2A and 2B CW MAGNETOS
AXMR2433	1	Condenser
R2437	1	Point Set
D2460A	2	Dist. Brush Assembly
E2460B	1	Brush Assembly
P2765	1	Distributor Rotor
A5931B	1	Lockwasher
10S14D	4	End Cap Screw
GK16	1	Gasket Kit
		KIT NO. SK23 for FM-XE4B CW MAGNETOS
SXY2433	1	Condenser
A2437A	1	Point Set
E2460B	1	Brush Assembly
X2765	1	Distributor Rotor
A5931B	1	Lockwasher
10S12D	2	End Cap Screw
10S18D	2	End Cap Screw
GK22	1	Gasket Kit
		KIT NO. SK27 for FM-E6 CW MAGNETOS
E983B	1	Suppressor Assembly
DX2433	1	Condenser
A2437A	1	Point Set

Part No.	Quantity	Description
		KIT NO. SK27 (Continued)
W2474	1	Distributor Block
Z2765	1	Distributor Rotor
		KIT NO. SK28 for FM-XYE4B16K CW MAGNETOS
B983B	1	Suppressor Assembly
SXY2433	1	Condenser
A2437A	1	Point Set
G2474E	1	Distributor Block
X2765	1	Distributor Rotor
		KIT NO. SK29 for FM-E6B16U CW MAGNETOS
E983B	1	Suppressor Assembly
HX2433	1	Condenser
A2437A	1	Point Set
P2473	1	"O" Ring Seal
W2474	1	Distributor Block
Z2765	1	Distributor Rotor
		KIT NO. SK31 for FM-E6 MAGNETOS RADIO SHIELDED CONVERSION
D682A	1	End Cap Cover Gasket
C800A	1	End Cap Cover
E983B	1	High Tension Lead Rod Assembly
Z2430A	1	End Cap Complete
E2460B	1	Brush Spring Assembly
W2474	1	Distributor Block
M2498	1	End Cap to Housing Lead Gasket
B2741	4	Cable Outlet Knob
Z2765	1	Distributor Rotor
8S8D	4	End Cap Cover Screw
10S12D	2	End Cap Screw
10S22D	2	End Cap Screw
		KIT NO. SK33 for FM-X1B7E MAGNETOS
AXMR2433	1	Condenser
A2437A	1	Point Set
H2498	1	End Cap to Housing Gasket
		KIT NO. SK34 for FM-XV4B7 MAGNETOS
B682	1	End Cap Cover Gasket
SXY2433	1	Condenser
A2437A	1	Point Set
H2498	1	End Cap to Housing Gasket
		KIT NO. SK35 for FM-X1A7 MAGNETOS
AXMR2433	1	Condenser
B2437A	1	Point Set
H2498	1	End Cap to Housing Gasket
		KIT NO. SK36 for FM-X1-2B7 MAGNETOS
SXY2433	1	Condenser
A2437A	1	Point Set
H2498	1	End Cap to Housing Gasket
		KIT NO. SK37 for FM-XVE4B7G MAGNETOS
SXY2433	1	Condenser
A2437A	1	Point Set
K2498	1	End Cap to Housing Gasket
		KIT NO. SK38 for FM-X4B7A MAGNETOS
B682	1	End Cap Cover Gasket
AXMR2433	1	Condenser
A2437A	1	Point Set
H2498	1	End Cap to Housing Gasket
		KIT NO. SK43 for FM-XE2B7C MAGNETOS
SXY2433	1	Condenser
A2437AX	1	Point Set
K2498	1	End Cap to Housing Gasket
		KIT NO. SK44 for FM-ZVE4B7 MAGNETOS
V1498	1	Snap Ring
B1498B	1	Snap Ring
B1498D	1	Snap Ring
C1498G	1	Breaker Snap Ring

Part No.	Quantity	Description
		KIT NO. SK44 (Continued)
EX2433	1	Condenser
A2437A	1	Point Set
E2460B	1	Brush Assembly
P2473	1	"O" Ring Seal
A2492A	1	Seal Outer Washer
A2492C	2	Seal Inner Washer
K2498	1	End Cap to Housing Gasket
G3861	1	Rotor Shaft Seal
10S12D	2	End Cap Screw
		KIT NO. SK44-1 for FM-ZVE4B7 MAGNETOS
E682A	1	End Cap Cover Gasket
EX2433	1	Condenser
A2437A	1	Point Set
P2473	1	"O" Ring Seal
K2498	1	End Cap to Housing Gasket
		KIT NO. SK46 for FM-XZE4B16F, 16S and 16Z MAGNETOS
F983B	1	Suppressor Assembly
CX2433	1	Condenser
A2437A	1	Point Set
B2474E	1	Distributor Block
X2765	1	Distributor Rotor
		KIT NO. SK48 for WISCONSIN MOTORS
B682	1	End Cap Cover Gasket
B1498B	1	Snap Ring
C1498G	1	Breaker Snap Ring
SXY2433	1	Condenser
A2437A	1	Point Set
A2492A	1	Seal Outer Washer
H2498	1	End Cap to Housing Gasket
G3861	1	Rotor Shaft Seal
A5950A	1	Cam End Bearing
6S6U	2	Contact Support Screw
10S14D	4	End Cap Screw
8LW5	2	Gr. Switch Lockwasher
		KIT NO. SK49 for FM-X1A7 and FM-XD1B7R MAGNETOS
B1498B	1	Snap Ring
C1498G	1	Breaker Snap Ring
AXMR2433	1	Condenser
B2437A	1	Point Set
A2492A	1	Seal Outer Washer
H2498	1	End Cap to Housing Gasket
G3861	1	Rotor Shaft Seal
A5950A	1	Cam End Bearing
6S6U	2	Contact Support Screw
10S12D	4	End Cap Screw
8LW5	2	Ground Switch Lockwasher
		KIT NO. SK51 for FM-XE4B14E-1 MAGNETOS
D1498	1	Snap Ring
B1498B	1	Snap Ring
C1498D	1	Snap Ring
C1498G	1	Breaker Snap Ring
TX2433	1	Condenser
A2437AX	1	Point Set
E2460B	1	Brush Assembly
P2473	1	Seal
A2492A	1	Seal Outer Washer
A2492C	1	Seal Inner Washer
K2498	1	End Cap to Housing Gasket
C2723	1	Shim
G3861	1	Rotor Shaft Seal
A5950A	1	Cam End Bearing
D5950C	1	Distributor Bearing
10S12D	1	Screw
10S18D	1	Screw
		KIT NO. SK52 for FM-PE1-2B7C MAGNETOS
V1498	1	Snap Ring
C1498D	1	Snap Ring
A1498F	1	Snap Ring
RX2433	1	Condenser
Q2437AX	1	Point Set

Part No.	Quantity	Description
		KIT NO. SK52 (Continued)
A2492A	1	Seal Outer Washer
A2492C	1	Seal Inner Washer
N2498	1	End Cap to Housing Gasket
G3861	1	Rotor Shaft Seal
L6018	1	Insulator
10S12D	1	Screw
		KIT NO. SK53 for FM-XZE4B16F and 16S MAGNETOS
D1498	1	Snap Ring
G1498	1	Snap Ring
B1498B	1	Snap Ring
C1498G	1	Breaker Snap Ring
CX2433	1	Condenser
A2437AX	1	Point Set
E2460B	1	Brush Assembly
A2492A	1	Seal Outer Washer
A2492C	1	Seal Inner Washer
E2493	1	Retaining Washer
L2498	1	End Cap to Housing Gasket
C2723	1	Shim
G3861	1	Rotor Shaft Seal
D5950C	1	Distributor Bearing
10S12D	1	Screw
10S18D	1	Screw
		KIT NO. SK54 for FM-XDE1B7F MAGNETOS
V1498	1	Snap Ring
B1498B	1	Snap Ring
C1498D	1	Snap Ring
C1498G	1	Breaker Snap Ring
AXMR2433	1	Condenser
A2437AX	1	Point Set
E2460B	1	Brush Assembly
A2492A	1	Seal Outer Washer
A2492C	2	Seal Inner Washer
H2498	1	End Cap to Housing Gasket
K2498	1	End Cap to Housing Gasket
C2723	1	Shim
G3861	1	Rotor Shaft Seal
A5950A	1	Cam End Bearing
B5950D	1	Bearing
A6304	1	Seal
E6304A	1	Seal
B6340	1	Seal
10S8A	1	Screw
10S10A	1	Screw
10S12D	1	Screw
		KIT NO. SK55 for FM-XDE1B7S MAGNETOS
V1498	1	Snap Ring
B1498B	1	Snap Ring
C1498D	1	Snap Ring
C1498G	1	Breaker Snap Ring
SXY2433	1	Condenser
A2437AX	1	Point Set
A2492A	1	Seal Outer Washer
A2492C	1	Seal Inner Washer
K2498	1	End Cap to Housing Gasket
C2723	1	Shim
L2788	1	Breaker Arm Wick
G3861	1	Rotor Shaft Seal
A5950A	1	Cam End Bearing
10S12D	1	Screw
		KIT NO. SK56 for FM-XE4B16W MAGNETOS
D1948	1	Snap Ring
G1498	1	Snap Ring
B1498B	1	Snap Ring
B1498D	1	Snap Ring
C1498G	1	Breaker Snap Ring
MX2433	1	Condenser
A2437AX	1	Point Set
E2460B	1	Brush Assembly
P2473	1	Seal
A2492A	1	Seal Outer Washer
A2492C	1	Seal Inner Washer
L2498	1	End Cap to Housing Gasket

Part No.	Quantity	Description
		KIT NO. SK56 (Continued)
C2723	1	Shim
G3861	1	Rotor Shaft Seal
A5950A	1	Bearing
D5950C	1	Bearing
10S12D	1	Screw
10S18D	1	Screw
		KIT NO. SK57 for FM-E6A14D MAGNETOS
D1182	1	Suppressor Insulator
A1498A	1	Snap Ring
A1498D	1	Snap Ring
B1498B	1	Snap Ring
C1498D	1	Breaker Snap Ring
C1498G	1	Snap Ring
SXY2433	1	Condenser
B2437AX	1	Point Set
E2460B	1	Brush Assembly
B2473	1	Seal
P2473	1	Seal
A2492A	1	Seal Outer Washer
A2492C	2	Seal Inner Washer
K2498	1	End Cap to Housing Gasket
M2498	1	End Cap to Housing Gasket
Q2498	1	End Cap to Housing Gasket
C2723	1	Shim
D3861	1	Seal
G3861	1	Seal
A5950A	1	Bearing
D5950C	1	Bearing
A6304	1	Seal
10S12D	1	Screw
10S18D	1	Screw
10S22D	1	Screw
		KIT NO. SK58 for FM-E6B16P MAGNETOS
D1182	1	Suppressor Insulator
A1498A	1	Snap Ring
A1498D	1	Snap Ring
C1498D	1	Snap Ring
C1498G	1	Breaker Snap Ring
HX2433	1	Condenser
A2437AX	1	Point Set
E2460B	1	Brush Assembly
P2473	1	Seal
A2492A	1	Seal Outer Washer
A2492C	1	Seal Inner Washer
M2498	1	End Cap to Housing Gasket
C2723	1	Shim
G3861	1	Seal
A6304	1	Seal
10S12D	1	Screw
10S22D	1	Screw
		KIT NO. SK59
D1182	1	Suppressor Insulator
D1498	1	Snap Ring
G1498	1	Snap Ring
V1498	1	Snap Ring
A1498A	1	Snap Ring
A1498D	1	Snap Ring
B1498D	1	Snap Ring
C1498D	1	Snap Ring
C1498G	1	Breaker Snap Ring
SXY2433	1	Condenser
A2437AX	1	Point Set
E2460B	1	Brush Assembly
B2473	1	Seal
P2473	1	Seal
A2492A	1	Seal Outer Washer
A2492C	1	Seal Inner Washer
F2498	1	End Cap to Housing Gasket
H2498	1	End Cap to Housing Gasket
K2498	1	End Cap to Housing Gasket
L2498	1	End Cap to Housing Gasket
M2498	1	End Cap to Housing Gasket
N2498	1	End Cap to Housing Gasket
C2723	2	Shim
D3861	1	Seal

Part No.	Quantity	Description
		KIT NO. SK59 (Continued)
G3861	1	Seal
A5950A	1	Bearing
D5950C	1	Bearing
A6304	1	Seal
E6304A	1	Seal
10S12D	2	Screw
10S18D	1	Screw
		KIT NO. SK60 for FM-JE4B16A MAGNETOS
B983B	1	Suppressor Assembly
D1182	1	Suppressor Insulator
D1498	2	Snap Ring
B1498B	1	Snap Ring
B1498D	1	Snap Ring
C1498D	1	Snap Ring
A1498E	1	Snap Ring
AXMR2433	1	Condenser
R2437X	1	Point Set
E2460B	1	Brush Assembly
B2473	1	"O" Ring Seal
P2473	1	"O" Ring Seal
A2492A	1	Seal Outer Washer
A2492C	1	Seal Inner Washer
H2498	1	End Cap to Housing Gasket
K2498	1	End Cap to Housing Gasket
M2498	1	End Cap to Housing Gasket
C2723	1	Shim
G3861	1	Rotor Shaft Seal
A5950A	1	Cam End Bearing
B5950A	1	Cam End Bearing
B5950C	1	Distributor Bearing
D5950C	1	Distributor Bearing
A6304	1	Seal Washer
10S14A	1	Screw
10S12D	2	Screw
		KIT NO. SK61 for FM-E6B16J MAGNETOS
D1182	1	Suppressor Insulator
A1498A	1	Snap Ring
A1498D	1	Snap Ring
C1498G	1	Breaker Snap Ring
DX2433	1	Condenser
A2437AX	1	Point Set
E2460B	1	Brush Assembly
P2473	1	"O" Ring Seal
A2492A	1	Seal Outer Washer
A2492C	1	Seal Inner Washer
M2498	1	End Cap to Housing Gasket
C2723	2	Shim
G3861	1	Rotor Shaft Seal
A6304	1	Seal
10S12D	1	Screw
10S22D	1	Screw
		KIT NO. SK62
D1498	1	Snap Ring
G1498	1	Snap Ring
B1498B	1	Snap Ring
C1498D	1	Snap Ring
C1498G	1	Breaker Snap Ring
AXMR2433	1	Condenser
A2437AX	1	Point Set
E2460B	1	Brush Assembly
B2473	1	"O" Ring Seal
A2492A	1	Seal Outer Washer
A2492C	2	Seal Inner Washer
H2498	1	End Cap to Housing Gasket
K2498	1	End Cap to Housing Gasket
C2723	1	Shim
G3861	1	Rotor Shaft Seal
A5950A	1	Bearing
D5950C	1	Bearing
A6304	1	Seal
10S12D	1	Screw
10S14D	1	Screw
10S18D	1	Screw

Part No.	Quantity	Description
		KIT NO. SK63 for FM-PE1B7 MAGNETOS
V1498	1	Snap Ring
B1498B	1	Snap Ring
SXY2433	1	Condenser
Q2437AX	1	Point Set
A2492A	1	Seal Outer Washer
A2492C	1	Seal Inner Washer
A2492D	1	Retaining Washer
N2498	1	End Cap to Housing Gasket
G3861	1	Rotor Shaft Seal
10S12D	1	Screw
		KIT NO. SK66 for FM-XVE4B7G MAGNETOS
V1498	1	Snap Ring
B1498B	1	Snap Ring
C1498D	1	Snap Ring
C1498G	1	Breaker Snap Ring
SXY2433	1	Condenser
A2437AX	1	Point Set
E2460B	1	Brush Assembly
A2492A	1	Seal Outer Washer
A2492C	1	Seal Inner Washer
H2498	1	End Cap to Housing Gasket
K2498	1	End Cap to Housing Gasket
C2723	1	Shim
G3861	1	Rotor Shaft Seal
A6304	1	Seal
10S8A	1	Screw
10S12D	2	Screw
		KIT NO. SK67 for FM-E6B8M MAGNETOS
D1182	1	Suppressor Insulator
A1498A	1	Snap Ring
C1498D	1	Snap Ring
C1498G	1	Breaker Snap Ring
HX2433	1	Condenser
A2437AX	1	Point Set
E2460B	1	Brush Assembly
P2473	1	"O" Ring Seal
A2492A	1	Seal Outer Washer
A2492C	1	Seal Inner Washer
M2498	1	End Cap to Housing Gasket
C2723	1	Shim
G3861	1	Rotor Shaft Seal
A6304	1	Seal
10S12D	1	Screw
10S22D	1	Screw
		KIT NO. SK68 for FM-XZE4B16F MAGNETOS
D1182	1	Suppressor Insulator
D1498	1	Snap Ring
G1498	1	Snap Ring
B1498B	1	Snap Ring
C1498D	1	Snap Ring
C1498G	1	Breaker Snap Ring
CX2433	1	Condenser
A2437AX	1	Point Set
E2460B	1	Brush Assembly
A2492A	1	Seal Outer Washer
A2492C	1	Seal Inner Washer
E2493	1	Retaining Washer
K2498	1	End Cap to Housing Gasket
L2498	1	End Cap to Housing Gasket
C2723	1	Shim
G3861	1	Rotor Shaft Seal
A5950A	1	Bearing
D5950C	1	Bearing
10S12D	1	Screw
10S18D	1	Screw
		KIT NO. SK69 for FM-E6A14G CCW MAGNETOS
D1182	1	Suppressor Insulator
C1498	1	Snap Ring
A1498A	1	Snap Ring
C1498G	1	Snap Ring
HX2433	1	Condenser

Part No.	Quantity	Description
		KIT NO. SK69 (Continued)
B2437AX	1	Point Set
E2460B	1	Brush Assembly
P2473	1	"O" Ring Seal
A2492A	1	Seal Inner Washer
A2492C	1	Seal Outer Washer
M2498	1	End Cap to Housing Gasket
C2723	1	Shim
G3861	1	Rotor Shaft Seal
A6304	1	Seal
10S12D	1	Screw
10S22D	1	Screw
		KIT NO. SK71 for FM-XE1B93 CCW MAGNETOS
B1498B	1	Snap Ring
C1498D	1	Snap Ring
C1498G	1	Breaker Snap Ring
AXMR2433	1	Condenser
B2437AX	1	Point Set
B2473	1	"O" Ring Seal
A2492A	1	Seal Outer Washer
A2492C	2	Seal Inner Washer
H2498	1	End Cap to Housing Gasket
K2498	1	End Cap to Housing Gasket
C2723	1	Shim
G3861	1	Rotor Shaft Seal
A5950A	1	Bearing
10S12D	2	Screw
		KIT NO. SK72 for FM-PE1-2B7E2 MAGNETOS
V1498	1	Snap Ring
B1498D	1	Snap Ring
QX2433	1	Condenser
Q2437A	1	Point Set
P2473	1	"O" Ring Seal
A2492A	1	Seal Outer Washer
A2492C	1	Seal Inner Washer
A2492D	1	Retaining Washer
E2493	1	Retaining Washer
N2498	1	End Cap to Housing Gasket
G3861	1	Rotor Shaft Seal
C4373	1	Bushing
10S12D	4	Screw
		KIT NO. SK73 for PPT2477G SHIELDED TRANSFORMER
K1077	1	Cable Ferrule
N1077	2	Ferrule
P1077	1	Ground Ferrule
E1182	1	Transformer Insulator
B2473	1	Seal
A2735	1	Outlet Nut
D2735A	2	Cable Outlet Nut
B3967	1	Coil Spring
F4373	2	Spacer
G4373	2	Bushing
		KIT NO. SK74 to CONVERT FM-LTR6 to FM-LTRE6 SHIELDED MAGNETO
G682A	1	End Cap Cover Gasket
P800A	1	End Cap Cover Assembly
B2430D	1	End Cap Assembly
F2498	1	End Cap to Housing Gasket
8S8D	4	Screw
		KIT NO. SK75 to CONVERT FM-LTR4 to FM-LTRE4 SHIELDED MAGNETO
G682A	1	End Cap Cover Gasket
Q800A	1	End Cap Cover Assembly

Part No.	Quantity	Description
		KIT NO. SK75 (Continued)
B2430D	1	End Cap Assembly
F2498	1	End Cap to Housing Gasket
8S8D	4	Screw
		KIT NO. SK76 to CONVERT FM-LTR6 to FM-LTRD6 QUICK DISCONNECT TERMINATION MAGNETO
G682A	2	End Cap Cover Gasket
R800A	1	End Cap Cover Assembly
A2092	1	Plug Connector
C2430D	1	End Cap Assembly
F2498	1	End Cap to Housing Gasket
8S18N	4	Screw
8LW6	4	Lockwasher
		KIT NO. SK77 for FM-ZVE4B7 CW MAGNETOS
V1498	1	Snap Ring
B1498B	1	Snap Ring
C1498D	1	Snap Ring
C1498G	1	Breaker Snap Ring
EX2433	1	Condenser
A2437A	1	Point Set
E2460B	1	Brush Assembly
P2473	1	"O" Ring Seal
A2492A	1	Seal Outer Washer
A2492C	1	Seal Inner Washer
K2498	1	End Cap to Housing Gasket
C2723	1	Shim
G3861	1	Rotor Shaft Seal
A3604	1	Seal
10S12D	2	Screw
		KIT NO. SK78 for FM-XVE4C73A CCW MAGNETOS
V1498	1	Snap Ring
C1498G	1	Breaker Snap Ring
AXMR2433	1	Condenser
B2437AX	1	Point Set
E2460B	1	Brush Assembly
A2492A	1	Seal Outer Washer
A2492C	1	Seal Inner Washer
K2498	1	End Cap to Housing Gasket
C2723	2	Shim
G3861	1	Rotor Shaft Seal
B5950D	1	Bearing
A6304	1	Seal
E6304A	1	Seal
B6340	1	Seal
10S12D	1	Screw
		KIT NO. SK79 for FM-XDE1B7U-2 CW MAGNETOS
B1498B	1	Snap Ring
B1498D	1	Snap Ring
C1498G	1	Breaker Snap Ring
QX2433	1	Condenser
A2437A	1	Point Set
P2473	1	"O" Ring Seal
A2492A	1	Seal Outer Washer
A2492C	1	Seal Inner Washer
K2498	1	End Cap to Housing Gasket
C2723	2	Shim
G3861	1	Rotor Shaft Seal
10S12D	2	Screw
		KIT NO. SK80 for FM-H6B16 MAGNETOS
RX2433	1	Condenser
V2437	1	Point Set
E2460B	1	Brush Assembly

Part No.	Quantity	Description
		KIT NO. SK80 (Continued)
A2492C	1	Seal Inner Washer
F2498	1	End Cap to Housing Gasket
C2723	1	Shim
D3861	1	Seal
A5950C	1	Bearing
A6304	1	Seal
10S12D	2	Screw
		KIT NO. SK81 to CONVERT FM-LTR4 to FM-LTRD4 QUICK DISCONNECT TERMINATION MAGNETO
G682A	2	Gasket
R800A	1	End Cap Cover
A2092	1	Plug Connector
D2430D	1	End Cap
F2498	1	End Cap to Housing Gasket
8S18N	4	Screw
8LW6	4	Lockwasher
		KIT NO. SK82 for FM-LTP4-1B28 MAGNETOS
RX2433	1	Condenser
Q2437A	1	Point Set
F2460A	1	Dist. Brush Assembly
F2460B	1	Center Brush Assembly
H2498	1	Gasket
JX2765	1	Distributor Disc
		KIT NO. SK86 for FM-XY6B16 MAGNETOS
SXY2433	1	Condenser
A2437A	1	Point Set
W2765	1	Distributor Rotor
GK27	1	Gasket Kit
		KIT NO. SK87 for FM-LTR6 MAGNETOS
G682A	1	Gasket
RX2433	1	Condenser
S2437A	1	Point Set
F2460A	1	Brush Assembly
F2498	1	Gasket
D2788	1	Cam Wick
		KIT NO. SK88 for FM-LTR6 MAGNETOS
G682A	1	Gasket
D1498B	1	Snap Ring
RX2433	1	Condenser
S2437A	1	Point Set
F2460A	1	Brush Assembly
A2492A	1	Seal Outer Washer
A2492C	1	Seal Inner Washer
A2492D	1	Retaining Washer
F2498	1	Gasket
D2788	1	Cam Wick
G3861	1	Shaft Seal
JY4631	1	Bearing Support
C5949	1	Bearing
		KIT NO. SK90 for FM-XZE4B7-4 MAGNETOS
MX2433	1	Condenser
A2437A	1	Point Set
P2473	1	"O" Ring
L2474E	1	Distributor Block
X2765	1	Distributor Rotor
		KIT NO. SK92 for FM-P1B26 MAGNETOS
RX2433	1	Condenser
Q2437A	1	Point Set
H2498	1	Gasket