FILE IN THE

ERQ

prestolite SERVICE MANUAL

WINDSHIELD WIPER MOTOR SECTION

(Issued 3-16-78)

VOLTS	12	BRUSHES	2	POLES	2

ROTATION — Motor rotates clockwise at drive end. Crank arm rotates counterclockwise. Reverse rotations to park.

BEARINGS — Absorbent bronze

LUBRICATION — At overhaul, saturate the felt oiling pads around the armature shaft bearings with SAE 20 oil. Drain off excess oil. Apply a thin film of grease to the crank arm shaft before assembly. Fill gear chamber 3/4 full with a good grade gear grease.

END PLAY — .003" to .010". Adjust by turning adjusting screw in or out as required. Replace the adjusting screw if nylon lock becomes worn so that it will not hold the setting.

FIELD COIL DRAW — (70°F.) 1.8 to 2.0 at 12.0 volts. (Shunt field only)

NO LOAD DRAW — (70°F.) 2.5 maximum amperes at 12.0 volts. (Low speed operation)

TEST CONNECTIONS

LOW SPEED
Connect battery positive to black and red leads. Connect battery negative to yellow lead and motor frame. Blue lead, no connection.

HIGH SPEED
Same connections as low speed except add a 17 ohm resistor between the black lead and red lead.

PARK
Connect battery positive to blue lead. Connect black lead to yellow lead. Connect battery negative to red lead and motor frame.

PARKING ADJUSTMENT — Have motor cold and test with a load on the crank arm. Adjust to parking angle shown in tabulation by moving the switch plate adjustment. Final adjustment should be made after installatior using a wet windshield.

Unit	Parking Angle
ERQ-4001	A
ERQ-4002	B
ERQ-4003	A
ERQ-4005	C
ERQ-4006	D

Printed in U.S.A.

PARKING ANGLE

A. Crank arm should be pointing inward 31° ± 5° before passing a line parallel to the motor centerline.

B. Crank arm should be pointing outward 23° ± 5° before passing a line parallel to the motor centerline

C. Crank arm should be pointing outward 28° ± 5° after passing a line parallel to the motor centerline.

D. Crank arm should be pointing outward directly in line ± 5° with the motor centerline.

