



TECH TIPS

Dixie Part Numbers: A-1705 A-1758 TBA

Applications:	2011 Vehicles with OnStar® as listed below:		
Cadillac CTS	Cadillac Escalade	Cadillac SRX	Chevrolet Avalanche
Chevrolet Aveo	Chevrolet Camaro	Chevrolet Colorado	Chevrolet Corvette
Chevrolet Cruze	Chevrolet Equinox	Chevrolet Express	Chevrolet Impala
Chevrolet Malibu	Chevrolet Orlando	Chevrolet Silverado	Chevrolet Sonic
Chevrolet Traverse	GMC Acadia	GMC Canyon	GMC Savanah
GMC Sierra	GMC Tahoe	GMC Terrian	GMC Yukon

Conditions: The operator of the vehicle may complain that the vehicle does not crank or start and that the battery is dead or low. Additionally once restarted the OnStar® on “LED” may not be illuminated (when checking 1 minute after starting the engine).

Cause: A potential cause for the above is that the OnStar® system may keep various modules from going into the sleep mode.

Correction: Follow the manufacturer’s diagnostic and repair procedures which include measuring the parasitic drain for 10 minutes (do not open doors or activate locks etc. during the test). If the parasitic drain remains over 380 mA remove the OnStar® fuse or disconnect the OnStar® module connector and perform the test again.