



TECH TIPS

Dixie Part Numbers: A-1705 A-1758 S-1468 S-1490
 S-1511 S-80060 S-80302

Applications: 2007 – 2009 Cadillac Escalade (including ESV and EXT packages)
 2007 – 2009 Chevrolet Avalanche
 2007 – 2009 Chevrolet Silverado
 2007 – 2009 Chevrolet Suburban
 2007 – 2009 Chevrolet Tahoe
 2007 – 2009 GMC Sierra
 2007 – 2009 GMC Yukon (including Denali package)
 2007 – 2009 GMC Yukon XL (including Denali package)

Condition: The operator of vehicle may complain of one or more of the following conditions:
 - The vehicle fails to crank or start.
 - The battery intermittently goes dead.
 The technician may observe that there are no trouble codes stored in the system.

Cause: The manufacturer has identified several areas to inspect for quiescent draw in the system (also referred to as parasitic drain, parasitic load, quiet draw etc.). Areas of concern include but are not limited to:
 - An out-dated calibration file for the body control module.
 - Potentials short-circuit in the courtesy lighting system resulting in the fuse blowing (circuits 6815 and 6817).
 - A malfunction in the rear door lock mechanism
 - C0900 code stored in the system (over voltage)
 - Interior light left on.
 - Fuel pump relay staying on (buzzing at rear of vehicle).
 - Poor connections to the battery posts
 - Addition of after-market anti-theft devices.
 - Wires shorting or chaffing in the pillar

Correction: Refer to *TechTip TSB-006* for tips on how to perform the quiescent draw test and follow the manufacturer's recommended procedures to correct the problems as required.