




ELECTRICAL DIAGRAM - DEUTZ ENGINE - BEGINS WITH SN6F0146

Ref #	Part
1	215-046 SAFETY SWITCH
2	215-051 IGNITION SWITCH (INCL. KEYS)
4	215-087 SAFETY SWITCH
5	215-098 SHUTOFF SOLENOID
6	215-113 OIL PRESSURE SFNDER
7	215-118 TACHOMETER
8	215-129 VOLTMETER
9	215-131 OIL GAUGE
10	215-133 FUEL GAUGE
11	215-137 FUEL SENDER
12	215-161 ALTERNATOR
13	215-255 BATTERY
14	215-321 BATTERY CABLE (60" LG)
15	215-323 BATTERY CABLE (40" LG)
16	215-443 RED PILOT LIGHT
17	215-445 AMBER PILOT LIGHT
19	215-477 QUICK CONNECTOR (16 GA)
20	215-478 BUTT CONNECTOR (16 GA)
21	215-492 2-WIRE (14 GA)--USE 54"
22	215-499 WIRE (16 GA X 18")
23	215-525 RING TERMINAL (5/16")
24	215-530 SPADE TERMINAL (NO. 10)
25	215-564 WIRE (16 GA X 18")
26	215-584 MALE TERMINAL (1/4")
27	215-601 CENTER CONSOLE HARNESS
28	215-606 LEFT CONSOLE HARNESS
29	215-607 RIGHT CONSOLE HARNESS
30	215-609 FRAME HARNESS
31	215-617 WIRE (16 GA X 10")
32	215-684 ENGINE HARNESS
33	306-601 HORN