

LESTER PLUG CODE	JIMCO TEST LEAD		LESTER PLUG CODE	JIMCO TEST LEAD	
9801-063	TB-COM1	"COM"	9801-210	TB-CD	
9801-078	TB-COM1	"COM/DFM"	9801-220	TB-MD	
9801-100	TB-M		9801-221	TB-MD	
9801-1006	CALL		9801-230	TB-39	
9801-101	TB-57		9801-231	TB-4	
9801-102	TB-48		9801-240	TB-39	
9801-107	TB-A		9801-241	TB-44	
9801-108	TB-FV		9801-242	TB-41	
9801-109	TB-FV		9801-250	TB-S	
9801-110	TB-B		9801-251	TB-T	
9801-111	TB-BM		9801-255	TB-74	
9801-112	CALL		9801-260	TB-46	
9801-113	TB-M	TB-VO	9801-261	TB-41	
9801-114	TB-VO		9801-270	TB-W	
9801-120	TB-O		9801-271	TB-65	
9801-130	TB-J		9801-272	TB-W	
9801-131	NO APPLICATION		9801-280	TB-42S	TB-52C
9801-140	TB-39		9801-282	TB-42S	TB-52C
9801-149	TB-FC	TB-UNI	9801-284	TB42S	TB-52C
9801-150	TB-C		9801-285	TB-59	
9801-151	TB-C		9801-286	TB-SP3	TB-UNI TB-42S TB-52C
9801-152	NO APPLICATION		9801-287	TB-SP3	TB-UNI TB-42S TB-52C
9801-153	TB-D		9801-290	TB-43S	TB-43S/79S
9801-154	TB-C3		9801-292	TB-43S	TB-43S/79S
9801-155	TB-C3		9801-294	TB-43S	TB-43S/79S
9801-160	TB-FC	TB-UNI	9801-295	TB-79S	TB-43S/79S
9801-161	TB-FT	TB-UNI	9801-296	TB-79S	TB-43/79C
9801-170	TB-FT	TB-UNI	9801-297	TB-79S	UNPLUG RED
9801-180	TB-FT	TB-UNI	9801-298	TB-SP3	TB-UNI
9801-181	TB-FV	TB-UNI	9801-300	TB-SL	TB-81
9801-190	TB-G		9801-301	TB-SL	
9801-191	TB-H		9801-302	TB-69	
9801-192	TB-H		9801-303	TB-82	
9801-193	TB-H		9801-304	TB-SL	
9801-194	TB-F		9801-305	TB-75	
9801-200	TB-ID		9801-306	TB-75	

LESTER
PLUG CODE TEST LEADLESTER
PLUG CODE TEST LEAD

9801-307	TB-75		
9801-308	TB-8S	TB-53C	TB-8S/53S
9801-309	TB-8S	TB-53C	TB-8S/53S
9801-309R	TB-8S/53S	TB-53C	
9801-310	TB-8S	TB-53C	TB-8S/53S
9801-311	TB-84	TB-52S	TB-52C
9801-312	TB-52S	TB-52C	
9801-313	TB-53S	TB-53C	TB-8S/53S
9801-314	TB-53S	TB-53C	TB-8S/53S
9801-315	TB-53S	TB-53C	TB-8S/53S
9801-316	TB-80		
9801-317	TB-55S		
9801-318	TB-55S		
9801-319	TB-55S		
9801-320	TB-68		
9801-321	TB-80		
9801-322	TB-53S	TB-53C	TB-8S/53S
9801-323	TB-53S	TB-53C	TB-8S/53S
9801-324	TB-86		
9801-325	TB-55S		
9801-326	TB-97C		
9801-327	NO APPLICATION		
9801-328	NO APPLICATION		
9801-329	NO APPLICATION		
9801-330	TB-3G		
9801-331	TB-3G		
9801-332	TB-6G	TB-88	
9801-333	TB-3G		
9801-334	TB-3G		
9801-335	TB-85		
9801-336	TB-6G	TB-88	
9801-337	TB-88	TB-88S	
9801-338	TB-6G	TB-88	
9801-339	TB-88/w/TB88A	TB-88S/w/TB-88A	
9801-340	TB-71		
9801-341	TB-92		

9801-342	NO APPLICATION	
9801-343	NO APPLICATION	
9801-344	TB-88/w/TB-88B	TB-88S/w/TB-88B
9801-346	TB-97C	
9801-350	TB-61	
9801-351	TB-62S	TB-62
9801-352	TB-61	TB-89
9801-353	TB-62S	TB-62
9801-358	TB-98	
9801-360	TB-63	
9801-361	TB-64	
9801-362	TB-LN	
9801-363	TB-LN	
9801-364	TB-91	
9801-365	TB-97C	
9801-366	TB-90	
9801-367	TB-93	
9801-368	TB-LN	
9801-369	TB-L	
9801-370	TB-FV	
9801-371	TB-FV	
9801-372	TB-FV	
9801-373	TB-FV	
9801-374	TB-L	
9801-375	TB-L	
9801-376	TB-LW	
9801-377	TB-LC	
9801-378	TB-LC	
9801-380	TB-FV	
9801-381	TB-96	
9801-399	TB-M	
9801-400	TB-UNI	
9801-401	TB-UNI	
9801-402	TB-UNI	
9801-403	TB-UNI	
9801-404	TB-96	

LESTER JIMCO
PLUG CODE TEST LEADLESTER JIMCO
PLUG CODE TEST LEAD

9801-405	TB-96	
9801-406	TB-UNI	
9801-407	TB-UNI	
9801-408	TB-UNI	
9801-409	TB-96	
9801-410	TB-UNI	
9801-425	CALL	
9801-427	TB-427	
9801-428	CALL	
9801-430	CALL	
9801-433	TB-FV	
9801-435	CALL	
9801-442	CALL	
9801-917	TB-79S	TB-43/79C
9801-929	TB-60	
9801-932	TB-79S	TB-43/79C
9801-933	TB-79S	TB-43/79C