Colt Industries

# Fairbanks Morse

Engine Accessories Operation


BELOIT, WISCONSIN 53511

SERVICE INFORMATION
Series 2000 Magnetos
Generator Coil Position

Subject: Correct Position of Generator Coil by Rotation


Black wire to #6 terminal; Brown wire to #8 terminal; Red wire to #10 terminal

FV2477C





CW & CCW

HV2477C





CW & CCW

BV2477C





CCW

GV2477C





CCW

JV2477C





CCW

YV2477C





CCW

GV2477C





CW

JV2477C




CW

YV2477C




CW

Rotor is below the coil when coil is in position as shown above.