prestolite®

SERVICE PARTS LIST

GHH SERIES

GENERATOR


ISSUED: 9-18-73(Rev.)

ORIG.EQUIP.GEN. SERVICE GEN. VOLTS-12

ENG. NUMBER		ENG. NUMBER	SALES NUMBER	APPLICATION
GHH-6001E	USE	GKJ-7303S	45-48	Allis-Chalmers
GHH-6001F	USE	GKJ-7303S	45-48	Continental,Wisconsin
GHH-6001G	USE	GKJ-7303S	45-48	Lister Blackstone
GHH-6001H	USE	GKJ-7303S	45-48	U.S.Motors
GHH-6001H-1	USE	GKJ-7303S	45-48	Towmotor(#53624)
GHH-6001J	USE	GKJ-7303S	45-48	J.I.Case,Towmotor
GHH-6001L	USE	GKJ-7303S	45-48	Tractomotive
GHH-6001S	USE	GKJ-7303S	45-48	Continental
GHH-6001SN	USE	GKJ-7303SN	45-49	Westinghouse Air Brake
GHH-6002B		GHH-6002B	- - -	J.I.Case
GHH-6002C	USE	GJT-7301SN-1	45-732	Towmotor(#C-57609)
GHH-6002S		GHH-6002S	45-96	J.I.Case
GHH-6002SN		GHH-6002SN	45-213	Service
GHH-6003A		GHH-6003A	45-326	Massey-Ferguson
GHH-6004A	USE	GHH-6004S	45-212	Towmotor(#C-52167)
GHH-6004S		GHH-6004S	45-212	Service

NOTE: SEE TABLE FOR GENERATOR BEING SERVICED WHEN PARTS ARE REQUIRED.

GHH Series Generator Parts List



Exploded View of Typical GHH Generator

Assembly	Armature (1)	Brush Set (2)	Field Coil Assembly (3)	Comm. End Head Assembly (4)	C.E. Bearing (5)	Brush Arm & Spring Package (6)	C.E. Oiler (7)
GHH-6001E - - - -	10-49 (GHH-2006F)	11-6 (G8J-2012S)	13-20 (GHH-1005)	12-91 (GHH-2002S)	24-5 (GGU-38A)	90-378	35-49 (8X-2961)
GHH-6001F - - - -	"	"	"	"	"	"	"
GHH-6001G - - - -	"	"	"	"	"	"	"
GHH-6001H - - - -	"	"	"	"	"	"	"
GHH-6001H-1 - - - -	"	"	"	"	"	"	"
GHH-6001J - - - -	"	"	"				
GHH-6001L - - - -	"	"	"	"	"	"	"
GHH-6001S (45-94)	"	"	"	"	"	"	"
GHH-6001SN (45-95)	"	"	"	"	"	"	"
GHH-6002B - - - -	"	"	"	"	"	"	"
GHH-6002C - - - -	"	"	"	"	"	"	"
GHH-6002S (45-96)	"	"	"	"	"	"	"
GHH-6002SN (45-213)	"	"	"	"	"	"	"
GHH-6003A (45-326)	10-68 (GHH-2032F)	"	"	12-92 (GHH-2030S)	- - - -	"	"
GHH-6004A - - - -	10-49 (GHH-2006F)	"	"	12-160 (GHH-2003AF)	24-5 (GGU-38A)	"	31-2 (8X-1991)
GHH-6004S (45-212)	"	"	"	"	"	"	

GHH-6001E TO 6004S GENERATOR PARTS LIST

Assembly	Drive End Head Assembly (8)	D.E. Bearing (9)	Bearing Retainer Gasket (10)	D.E. Oiler (11)	Felt Washer (12)	D.E. Retainer (13)	Cover Band (14)
GHH-6001E	14-86 (GHD-10035)	25-6 (X-295)	35-217 (GEE-27)	35-49 (8X-2961)	35-21 (GG-164)	35-29 (GR-32)	35-250 (GHD-1024)
GHH-6001F	"	"	"	"	"	"	"
GHH-6001G	"	"	"	"	"	"	"
GHH-6001H	"	"	"	"	"	"	"
GHH-6001H-1	"	"	"	"	"	"	"
GHH-6001J	"	"	"	"	"	"	"
GHH-6001L	"	"	"	"	"	"	"
GHH-6001S (45-94)	"	"	"	"	"	"	"
GHH-6001SN (45-95)	"	"	"	"	"	"	"
GHH-6002B	"	"	"	"	"	"	"
GHH-6002C	"	"	"	"	"	"	"
GHH-6002S (45-96)	"	"	"	"	"	"	"
GHH-6002SN (45-273)	"	"	"	"	"	"	"
GHH-6003A (45-326)	"	"	"	"	"	"	"
GHH-6003H	14-172 (GHD-10038)	"	"	31-2 (8X-1590)	"	"	"
GHH-6004S (45-312)	"	"	"	"	"	"	"

Assembly	Terminal Stud Package (15)	Lead Assembly (16)	Thru Bolt Package (17)	Nut & Washer Package (18)	Armature Shaft Spacer (19)	Drive Pulley (20)	Regulator (21)
GHH-6001E - - - -	90-336	90-665	36-576 (MW-20AS)	90-33	35-253 (GJ-104B)	34-188 (SP-854A)	8-248 (VBX-4221B)
GHH-6001F - - - -	"	"	"		"	34-189 (SP-856)	
GHH-6001G - - - -	"	"	"	"	"	34-318 (PU-232BS)	"
GHH-6001H - - - -	"	"	"	"	- - - -	34-200 (SP-1344)	
GHH-6001H-1 - - - -	"	"	"	"	- - - -	"	
GHH-6001J - - - -		"			35-253 (GJ-104B)	34-166 (PU-161)	
GHH-6001L - - - -	"	"	"	"	"	34-237 (PU-250)	"
GHH-6001S (45-94)	"	"	"	"	"	- - - -	"
GHH-6001SN (45-95)	"	"	"	"	"	- - - -	"
GHH-6002B - - - -	"	- - - -	"		- - - -	34-184 (SP-383A)	8-248 (VBX-4202B)
GHH-6002C - - - -	"	- - - -	"	"	35-253 (GJ-104B)	34-165 (PU-160)	"
GHH-6002S (45-96)	"	- - - -	"	"	"	- - - -	"
GHH-6002SN (45-213)	"	- - - -	"	"	"	- - - -	"
GHH-6003A (45-326)	"	90-665	"		"	34-318 (PU-232BS)	8-248 (VBX-4221B)
GHH-6004A - - - -	"	- - - -	"		"	34-165 (PU-160)	8-248 (VBX-4202B)
GHH-6004S (45-212)	"	- - - -	"	"	"	- - - -	"